TOP AND CONSOLE PARTS

For Model: 7MWG66700SQ0, 7MWG66700ST0
(Designer White) (Biscuit)

29" GAS DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: 7MWG66700SQ0, 7MWG66700ST0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8564241	Installation Instructions
	8579961	Sheet, Cycle Feature
	8565897	Use & Care Guide
	8528190	Wiring Diagram
Following May Be Purchased		
DO−IT−YOURSELF REPAIR MANUALS		
	677818	Dryer
2	8533951	Screw, Grounding
3	3394427	Clip, Harness
4		Cap, End (L.H.)
	8565957	White
	8565958	Biscuit
5	3397269	Connector (Timer)
6	8274261	Panel, Rear Console
7	3395683	Housing, Connector (Motor)
8		Cap, End (R.H.)
	8565954	White
	8565955	Biscuit
9	694419	Buzzer, Mini
10		Lint Screen
	8557857	White
	8557858	Biscuit
11	8536939	Clip, Spring
12	8312709	Clip−Console
13	688983	Screw, 8−18 x 5/8
14	3401684	Wire, Jumper (Black)
15	693995	Screw, Hex Head
16		Top
	8559800	White
	8563660	Biscuit
18	3399639	Switch, End of Cycle
19		Knob, Control
	8565944	White
	8565947	Biscuit
20	8539893	Wire, Jumper (Guard On/Off)
21	8299765	Timer Assembly (60 Hz.)
22	3403499	Connector, 2−Position (Gas Valve)
23	3403498	Connector, 3−Position (Gas Valve)
24	3347243	Connector, 6−Circuit
29	8533971	Screw, 8−18 x 5/16
31	8299879	Harness, Wiring
32	3398095	Switch, Push−To−Start
33		Timer Knob Assembly
	8566061	White
	8566064	Biscuit
34		Knob, Push−To−Start
	8566073	White
	8566076	Biscuit
35	717252	Receptacle, 2−Way
36	94614	Terminal, Female
37	8566052	Bracket, Control
38		Panel, Control
	8543037	White
	8543038	Biscuit
39	3936144	Connector

CABINET PARTS

For Model: 7MWG66700SQ0, 7MWG66700ST0

(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: 7MWG66700SQ0, 7MWG66700ST0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	697776	Screw, 10−32 x 5/8 (External Ground)
2	343641	Screw, 10−16 x 1/2
3	3404162	Clamp, Motor (W/Shield)
4	8541400	Bracket, Cabinet
5	3396795	Cover, Block
6	693995	Screw, Hex Washer Head
7	3396805	Panel, Rear
8	8546676	Clip, Door Spring
10	3406109	Door Switch Assembly
11	697773	Screw, 6−20 x 7/8
12	3980175	Clamp−Elbow
13	694091	Screw, 8−18 x 3/8
14	8541401	Spring, Door (2)
15	3357011	Screw, 10−16 x 1/2
16	3392100	Foot, Dryer
	279810	Foot − Optional (Extended Length Package Of 2 (Not Included)
18		Cabinet (Includes Illus. 4)
	8530603	White
	8530606	Biscuit
19	98234	Clip, Ground (2)
20	690363	Lock, Front Top (2)
21		Panel Front
	3395197	White
	3977243	Biscuit
23	685203	Clip, Felt Pad (2)
24	3389441	Catch, Door Assembly
25	3390731	Seal, Door
26	337189	Clip, Hinge (2)
27	342043	Screw, 10−32 x 3/8
28	8066056	Hinge, R.H.
	8066057	Hinge, L.H.
29	3394083	Clip, Front Panel
33	696144	Strike, Panel
35	695737	Door, Rear
36		Door, Front
	3393549	White
	3977241	Biscuit
37		Handle, Door
	8566057	White
	8566069	Biscuit
38	3406129	Seal & Bearing Assembly
45	344020	Cord, Power
49		Plug, Front Panel
	3394975	White
	3394978	Biscuit
51	8066217	Hinge, Top (2)
53	691366	Idler & Pulley Assembly
56	8066065	Belt, Drive
57	348780	Base, Motor
58	3400500	Bolt, 5/16−18 x 3/4
59	8066184	Pulley, 60 Hz.
62	8066206	Motor Assembly 60 Hz.
63	660658	Clamp, Motor
67	8318272	Burner Assembly, 60 Hz. (See Pages 7 & 8 For Further Burner Breakdown)
68	341029	Clamp, Pipe

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: 7MWG66700SQ0, 7MWG66700ST0

(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Model: 7MWG66700SQ0, 7MWG66700ST0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	489463	Screw, 8−18 x 5/8
3	3388703	Washer−Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8−18 x 3/8
6	3406022	Bracket, Bulkhead
7	3392519	Fuse, Thermal
8	8066086	Drum Hole Plug
9	3387134	Thermostat, Internal−Bias
10	694089	Wheel, Blower (Includes Illus. 21)
11	8577230	Housing, Blower
12	8066155	Clip
13	343641	Screw, 10−16 x 1/2
14	8530285	Box, Heater
15	3403140	Thermostat, 205°F (96°C)
16	280010	Kit, Thermal Cut−Off (Includes Illus. 15)
17	3401707	Wire, Jumper
18	8066049	Funnel, Burner
19	3390647	Screw, 8−18 x 1/2
20	3403634	Socket, Assembly
22	3977373	Bracket, Light
23	3406124	Bulb, Light
24	3402841	Lens, Light
25	487909	Screw, 8−15 x 1/2
26	690997	Ring, Tri
27	3399506	Shaft, L.H.
28	3399507	Shaft, R.H.
29	3397590	Roller, Support
30	348197	Washer, Support
31	3359452	Nut, 3/8−16
32	3403493	Bulkhead
33	338906	Sensor, Radiant
34	692526	Ring, Bearing
35	97787	Screw, 11−16 x 3/4
36	3406130	Seal, Rear Drum
37	695587	Drum Assembly
38	692490	Baffle, Drum (2)
39	3976434	Bracket, Support
40	90296	Clip
41	3403636	Baffle, Drum (1)
42	339956	Seal
43	696302	Shield, Exhaust

8318272 BURNER ASSEMBLY

For Model: 7MWG66700SQ0, 7MWG66700ST0

(Designer White) (Biscuit)

USE WITH TYPE 1 − NATURAL

AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

8318272 BURNER ASSEMBLY

For Model: 7MWG66700SQ0, 7MWG66700ST0
(Designer White) (Biscuit)

USE WITH TYPE 1 − NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	8318272	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8−32 x 5/8)
6	343641	Screw, 10−16 x 1/2
7	693986	Base, Burner
8	3387057	Screw, 8−18 x 3/8
9		Orifice, Burner
	234826	Type 1
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	8318277	Valve, 60 Hz. (Includes Pipe & Illus. #7)
11	694421	Screw, 8−32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
25	341029	Clamp, Pipe

Following Parts Not Illustrated

694572	Conversion Kit (Type 1) to Type (4) L.P.G.

BA−150

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Model: 7MWG66700SQ0, 7MWG66700ST0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION

ACCESSORY PARTS

279948	Kit, Dryer Repair
8522199	Kit, Dryer Vent Testing
346764	Kit, Hold−Down (Gas Dryer Mobile Home Installation)
3404351	Dry Rack

PAINT, TOUCH−UP (1/2oz.)

72017	White
4392899	Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
4392901	Biscuit
350938	Primer, Gray

PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit (Uncut)